## ACK MODEL E-04 ELT INSTALATION TROUBLE SHOOTING CHECK LIST

New installation	Yes	No	If no how long in service		S/N	From TSO Labe
	E-04	general aviat	ion model	E-04C Com	nmercial model _	
		Des	cribe the probl	em you are exp	eriencing?	
		И	/hat type aircra	ft is the ELT ins	talled in	
Where is the	ELT mo	ounted in the	aircraft (Photo	showing ELT a	and surrounding	equipment and wiring))
		_	-			ransponder
ADS-B equipr	ment			<del></del>		
			Where is the re	mote control m	ounted	
Where is t	the remo	ote cable rou	ted. In relation	to the Comm co	ax, transponder	coax or ADS-B coax
		Wh	ere is the Audio	o Alert indicator	mounted	
WI	here is t	he antenna le	ocated (Photo)	Are you using o	our antenna Yes_	No
If No describe	e the an	tenna				
Distance from	: Neare	est Comm An	tenna	Transponder An	tenna	ADS-B Antenna
Is the static	c suppre	essor installe	ed YesNo	If Yes C	On the antenna_	On the ELT
Did the prob	blem oc	cur after add	ing avionics or	other electrical	equipment (Des	cribe what was added)
Dic	d you fo	llow our Pre-	-Installation che	ecklist before in	stalling? Yes	No
			Inadver	tent activation		
		ls t	the aircraft Han	gered Yes	No	
	Did	the ELT activ	ate in flight	_ During Taxi	After shutdov	wn
	Was	s it raining or	had it been rai	ning before acti	vation Yesl	Vo
If afte	r shutde	own how long	g since the airc	raft was flown_		
Was the ELT	T registe	ered Yes	No Were	you contacted b	y Search and Re	escue Yes No
How long a	fter the	activation di	d Search and R	escue contact y	ou	

The known causes of inadvertent activation are as follows

High levels of RF/EMF near or close to the ELT, antenna or cables. Such interference can be the result of the comm antennas being to close to the ELT antenna, transponder or transponder antenna, ADS-B equipment or transmit antenna, main battery or battery solenoid, strobe light power supply or strobe lights. ELT cables running along Comm antenna cables, transponder cables, Battery cables, strobe light cables etc.

The other know cause is water in the Remote, Audio Alert, or cable connections. Battery corrosion in the Audio Alert or Remote can also cause inadvertent activation.